

**RGB MINI ONLY - Not sold anymore
Do not use for RGBW**

**RGB MINI
2.1.0 (9600 8 N 1)**

Commands are repeated out of the serial port to pass to the next controller or device.
All commands must be terminated with a carriage return. You can use \r for this.

COMMAND	ACTION	NOTES	R	G	B
emallred	R on, G & B off		100%	0%	0%
emallgreen	G on, R & B off		0%	100%	0%
emallblue	B on, R & G off		0%	0%	100%
emmagenta	Magenta		100%	0%	100%
emcyan	Cyan		0%	100%	100%
emgold	Gold		100%	100%	0%
emrgbwhite	RGB White		100%	100%	100%
emorange	Orange		100%	14%	0%
emltblue	Light Blue		0%	75%	100%
emltgreen	Light Green		0%	255%	10%
emviolet	Violet		65%	0%	100%
empink	Pink		100%	0%	20%
emrgbww	WarmWhite		95%	5%	45%
emcycle	Color Cycle Starts color cycle				
empause	Pause Pauses color cycle				
emrampYY	Ramp time The ramp rate of change				
embrt	Brighten RGB Brightens all RGB levels by 4%				
embtr	Brighten Red Brightens red by 4%				
embtg	Brighten Green Brightens green by 4%				
embtb	Brighten Blue Brightens blue by 4%				
emdim	Dim RGB Dims all RGB levels by 4%				
emdmr	Dim Red Dims red by 4%				
emdmg	Dim Green Dims green by 4%				
emdmb	Dim Blue Dims blue by 4%				
emsprea	Save Preset A Stores all 3 channel levels				
emspreb	Save Preset B Stores all 3 channel levels				
emsprec	Save Preset C Stores all 3 channel levels				



COMMAND	ACTION	NOTES	R	G	B
emspred	Save Preset D	Stores all 3 channel levels			
emspree	Save Preset E	Stores all 3 channel levels			
emsprea	Recall Preset A	Recalls the preset (3 channels)			
emspreb	Recall Preset B	Recalls the preset (3 channels)			
emsprec	Recall Preset C	Recalls the preset (3 channels)			
emspred	Recall Preset D	Recalls the preset (3 channels)			
emspree	Recall Preset E	Recalls the preset (3 channels)			
emaloff	LED's off	All LED channels off			

